



Syncing Colored Lights

1. At your subpanel, flip the breaker switch labeled LIGHTS off and on 3 times.
2. Choose the WHITE color in the selection menu on your Jandy RS System.
3. Let stand on white for 10 minutes.
4. Lights should now sync.